
INSTRUCTION MANUAL





Please keep this manual and product code number for future reference and for ordering replacement parts if necessary.

GENERAL INSTRUCTIONS

- Read this manual carefully and completely before proceeding.
- It is recommended that you wear safety glasses at all times during the installation.

INSTALLATION OVER CERAMIC TILES

- If your shower door is to be installed over ceramic tiles, the tiles should lay completely under the wall jamb.
- Silicone should be used to seal the gap where the ceramic tiles meet the fixed panel.

NOTICE

- Caulking: no sealant is required inside the shower, unless otherwise stated.
- Some models are equipped with clear sealing gaskets.

CARE FOR YOUR SHOWER DOOR


- Never use scouring powder pads or sharp instruments on metal pieces or glass panels.
- An occasional wiping down with a mild soap diluted in water is all that is needed to keep the panels and metal parts looking new.
- We recommend wiping the glass panels with a squeegee after each use.


TOOLS REQUIRED

SPIRIT LEVEL	POWER DRILL	PENCIL	SILICONE	MALLET	
TAPE MEASURE	SCREW DRIVER	6mm&8mm(1/4" & 5/16") DRILL BITS	HACKSAW	SAFETY GLASSES	


 * Use a 6mm(1/4") drill bit for ceramic when drilling into ceramic tiles

CHOOSE A CONFIGURATION





PARTS LISTING



ITEM	PARTS	DIAGRAM	QTY	ITEM	PARTS	DIAGRAM	QTY
1	Guide rail bracket	B	2	9	Ø70 Roller	I I I I I I I I I I I I I I I I I I I	4
2	Track holder for fixed panel	M	2	10	Screw St5x40		2
3	Rail	Ô	1	11	Wall plugs	4	3
4	Fixed panel		1	12	Door seal		1
5	Wall mount bracket	Ĵ	1	13	Sliding door	o o.	1
6	Screw St4x30		1	14	Handle		1
7	Floor guide	Ø	1	15	Fixed panel seal	Ш	2
8	Anti-splash threshold	۶٦	1	16	Door seal	L LI	1

