
INSTRUCTION MANUAL





Please keep this manual and product code number for future reference and for ordering replacement parts if necessary.

GENERAL INSTRUCTIONS

- Read this manual carefully and completely before proceeding.
- It is recommended that you wear safety glasses at all times during the installation.

INSTALLATION OVER CERAMIC TILES

- If your shower door is to be installed over ceramic tiles, the tiles should lay completely under the wall jamb.
- Silicone should be used to seal the gap where the ceramic tiles meet the fixed panel.

NOTICE

- Caulking: no sealant is required inside the shower, unless otherwise stated.
- Some models are equipped with clear sealing gaskets.

CARE FOR YOUR SHOWER DOOR

metal parts looking new.


- Never use scouring powder pads or sharp instruments on metal pieces or glass panels.
 An occasional wiping down with a mild soap diluted in water is all that is needed to keep the panels and
- We recommend wiping the glass panels with a squeegee after each use.


TOOLS REQUIRED

SPIRIT LEVEL	POWER DRILL	PENCIL	SILICONE	MALLET
TAPE MEASURE	SCREW DRIVER	6mm&8mm(1/4" & 5/16") DRILL BITS	HACKSAW	SAFETY GLASSES


 $[\]mbox{\ensuremath{\mbox{\$}}}$ Use a 6mm(1/4") drill bit for ceramic when drilling into ceramic tiles

CHOOSE A CONFIGURATION





PARTS LISTING



ITEM	PARTS	DIAGRAM	QTY
1	Guide rail bracket		2
2	Track holder for fixed panel		2
3	Rail	\bigcirc	1
4	Fixed panel		1
5	Wall mount bracket	0	1
6	Screw St4x30		1
7	Floor guide	Ø	1
8	Anti-splash threshold	, F.	1

ITEM	PARTS	DIAGRAM	QTY
9	Ø70 Roller	D	4
10	Screw St5x40	8	2
11	Wall plugs	4	3
12	Door seal		1
13	Sliding door	0	1
14	Handle		1
15	Fixed panel seal	Ш	2
16	Door seal	Ŋ	1

